



3098 Research Dr.
Rochester Hills, Mi 48309
www.LongviewTM.com

LONGVIEW™

Towing Mirror

Tel: (248) 844-1400

Fax: (248) 844-2244

e-mail: info@LongviewTM.com

The **ORIGINAL** Slip On Mirror

Model 1000



| | | |
|-----------|---------------------|-----------|
| Chevrolet | Blazer | 1982-1992 |
| Chevrolet | Pickup | 1978-1995 |
| Chevrolet | Silverado & CK | 1984-1994 |
| Chevrolet | Suburban | 1978-1992 |
| Chevrolet | Van (G) | 1978-1995 |
| GMC | Pickup | 1978-1995 |
| GMC | Rally Wagon (Van) | 1978-1995 |
| GMC | Sierra | 1984-1994 |
| GMC | Vandura (Van) | 1978-1996 |
| GMC | Yukon XL & Suburban | 1978-1991 |

Model 1100



| | | |
|------------|---------------------------|-----------|
| Chevrolet | Astro | 1985-1989 |
| Chevrolet | S-10 Blazer & S-10 Pickup | 1982-1994 |
| GMC | Jimmy | 1982-1994 |
| GMC | S-15 Pickup | 1982-1993 |
| Oldsmobile | Bravada | 1982-1994 |

Model 1200



| | | |
|-----------|---------------------|-----------|
| Cadillac | Escalade | 1999-2000 |
| Chevrolet | Astro | 1986-2005 |
| Chevrolet | Blazer | 1990-1994 |
| Chevrolet | Pickup | 1995-1999 |
| Chevrolet | Silverado & CK | 1988-1998 |
| Chevrolet | Suburban | 1990-1999 |
| Chevrolet | Tahoe | 1992-2000 |
| GMC | Kodiak | 1992-1999 |
| GMC | Pickup | 1993-2000 |
| GMC | Safari | 1988-2005 |
| GMC | Sierra | 1995-1999 |
| GMC | Yukon | 1992-2000 |
| GMC | Yukon XL & Suburban | 1991-1999 |

Model 1300



| | | |
|------------|---------------------------|-----------|
| Chevrolet | Blazer | 1995-1998 |
| Chevrolet | S-10 Blazer & S-10 Pickup | 1994-1998 |
| GMC | Jimmy | 1995-1998 |
| GMC | S-15 Pickup | 1994-1998 |
| GMC | Sonoma | 1996-1998 |
| GMC | Envoy | 1995-1998 |
| Oldsmobile | Bravada | 1995-2000 |

Model 1400



| | | |
|------------|------------|-----------|
| Chevrolet | Venture | 1997-2005 |
| Oldsmobile | Silhouette | 1997-2005 |
| Pontiac | Montana | 1997-2005 |
| Pontiac | Transport | 1997-1999 |

Model 1500



| | | |
|-----------|---------------------|-----------|
| Cadillac | Escalade | 2000-2006 |
| Chevrolet | Avalanche | 2001-2006 |
| Chevrolet | Pickup | 1999-2006 |
| Chevrolet | Silverado & CK | 1999-2006 |
| Chevrolet | Suburban | 2000-2006 |
| Chevrolet | Tahoe | 2000-2006 |
| GMC | Pickup | 1999-2006 |
| GMC | Sierra | 1999-2006 |
| GMC | Yukon | 2000-2006 |
| GMC | Yukon XL & Suburban | 2000-2006 |

Model 2000*



* Only fits this style of OEM Mirror

| | | |
|------|------------------------------|-----------|
| Ford | Bronco | 1983-1998 |
| Ford | Bronco II | 1984-1990 |
| Ford | Club Wagon (Van) | 1983-1991 |
| Ford | Econoline (Van) | 1983-1991 |
| Ford | * F150,250, 350 & P/U Ranger | 1983-1998 |

Model 2100*



* Only fits this style of OEM Mirror

| | | |
|------|------------------------|-----------|
| Ford | Aerostar | 1990-1997 |
| Ford | Bronco | 1992-1996 |
| Ford | * F150 & Pickup Ranger | 1992-1997 |
| Ford | F250 & F350 | 1992-1998 |

Model 2200



| | | |
|-------|---------------|-----------|
| Ford | Explorer | 1988-1996 |
| Ford | Pickup Ranger | 1988-1996 |
| Mazda | Navaho | 1988-1995 |
















Model 2200A*



Made
in
USA

* Model will not fit Puddle Light Design

| | | |
|---------|-----------------------|-----------|
| Ford | Explorer & Sport Trac | 1996-2003 |
| Ford | Pickup Ranger | 1996-2001 |
| Mercury | Mountaineer | 1996-2001 |
| Mazda | B-3000 & B-4000 | 1994-2001 |

| | | | | |
|---|---|--|--|---|
| Model 2300 |  | Ford Ford Lincoln Lincoln Ford | F150 Std., F250 Light Duty Heritage Blackwood Navigator Expedition | 1997-2003 2004 2002 1998-2002 1997-2002 |
| Model 2300A |  | Ford Ford | F150 F250 Light Duty | 2004-2008 2004-2008 |
| Model 2400 |  | Ford Ford | F150 F250, F350 (Manual Only) | 1997-2001 1997-1998 |
| Model 2500 |  | Ford Ford | Club Wagon (Van) Econoline (Van) | 1992-2003 1992-2003 |
| Model 2600 |  | Ford Ford Ford | Excursion F250 (Light Duty) F350 & F450 (Light Duty) | 1999-2005 1999-2004 1999-2004 |
| Model 3000 |  | Dodge Dodge | Dakota (Pickup) Ram Pickup & Van (Electric & Manual) | 1994-1997 1986-1995 |
| Model 3100 |  | Dodge Dodge Dodge | Dakota, (Black Elec & Manual Mirror) Ram (Pickups) & Van Dakota (Pickup Chrome Mirror) | 1994-1997 1994-1997 1996-1997 |
| ** Will not fit 5 x 7 Sport for 6 x 9 Only | | | | |
| Model 3100A |  | Dodge Dodge Dodge Dodge Dodge | Ram 1500, 3500 Ram 2500 (Light Duty) ** Durango ** Dakota Full Size Van | 1998-2002 1998-2002 1998-2000 1998-2000 2000-2003 |
| Will not fit 5 x 7 Sport for 6 x 9 Only | | | | |
| Model 3100B |  | Dodge Dodge | Ram 1500 Ram 2500, 3500 (Light Duty) | 2003-2007 2003-2007 |
| Model 3200 |  | Jeep Jeep | Cherokee Comanche | 1984-1996 1984-1996 |
| Model 3300 |  | Chrysler Dodge Plymouth | Town & Country Caravan Voyager | 1991-1995 1991-1995 1991-1995 |
| Model 3300A |  | Chrysler Dodge Plymouth | Town & Country Caravan Voyager | 1996-2005 1996-2005 1996-2005 |
| Model 3400 |  | Jeep Jeep | Grand Cherokee Wagoneer | 1993-1998 1993-1998 |
| Model 3400 A |  | Jeep Jeep | Grand Cherokee Wagoneer | 1999-2004 1999-2004 |
| Model 4000 |  | Toyota Toyota | Sequoia Tundra | 2003-2007 2003-2006 |



3098 Research Dr.
Rochester Hills, MI 48309
www.LongviewTM.com

LONGVIEW™

Towing Mirror

Tel: (248) 844-1400
Fax: (248) 844-2244
e-mail: info@LongviewTM.com

The **ORIGINAL** Slip On Mirror



Call or Fax your order Today!

For the most up to date information visit our web site

www.LongviewTM.com